

www.codcorp.com



User Manual  
Manual d'Utilisateur  
Manual de Usuario  
Manual do Usuario  
Benutzerhandbuch  
ユーザーマニュアル  
設定コード表



Configuration Guide  
Guide de Configuration  
Guia de Configuración  
Programmierhandbuch  
設定コード表  
配置指南  
설치 가이드




YouTube.com/codecorporation



code  
REVOLUTIONIZING BARCODE READING


QUICK START GUIDE

CR950




code  
REVOLUTIONIZING BARCODE READING






USB Cable  
Cable d'USB  
Cable USB  
Cabo USB  
USB-Kabel  
USB ケーブル  
USB 线缆  
USB 케이블





RS232 Cable  
Cable de RS232  
Cable rs232  
Cabo RS232  
RS232-Kabel  
RS232 ケーブル  
RS232 线缆  
RS232 케이블



Power Supply  
Alimentation électrique  
Fuente de alimentación  
Fonte de alimentação  
Netzeil  
ACアダプタ  
充电器  
Power Supply




Included if Ordered  
Inclus si commande Includo si así lo ordena Includos se ordena  
Inbegriffen, wenn bestellt 注文時に追加 包括若订购 주문시 포함




Scanning  
 Lecture Escaneo Leitura Scannen  
 स्क्यान 扫描中 스캐닝

- ④ 2x (Speaker icon)
- ③ (Light icon)
- ② 3 Sec. (Power button icon)
- ① (Power plug icon)



Power On  
 Allumer Encender Ligar Einschalten  
 電源オン 電源开启 Power on



Set Up  
 Installation Instalación Instalação  
 Einrichten 設定 設置 刈込